The RFS-1000 VersalMAGE INTERFACE



VersalMAGE Software Corporation

7600 Grand River Road, Suite 230, Brighton, MI 48114 Sales: (810) 225-9720 Support: (810) 225-9720 Fax: (810) 225-9726 SALES E-Mail: <u>abrunner@versasoftware.com</u>

Introduction:

The VersalMAGE interface for the RFS-1000 is an ISIS interface which monitors the microfilm blip and TIFF image address together. The RFS-1000 can be used with or without an SQ Feeder.

The reasons for having an SQ Feeder may be as follows:

- 1. The customer wants it because <u>Kodak</u> told him he needs it. This is an important point because many systems have been set up by Kodak to require sequential imprinting.
- 2. Documents are grouped into batches. Usually this happens in batches which contain 100 Files, numbered from 00 to 99) and scanned/filmed before they are moved to data entry for manual keying of data fields. The imprinted number will be keyed along with the other data and it becomes the CAR retrieval number.

With the advent of new forms design and ICR/OCR technology applied, the need for sequential imprinters is not as great as it used to be. However ...

3. The imprinted number provides easy access to documents which must be retaken for any reason. (Overlaps, upside down, folded corners, bad exposure caused by dark document color or light writing on documents, etc., bleed through, and others).

Some users may feel that the reasons for attaching an SQ Feeder become somewhat less important for <u>hybrid</u> filmer scanners because images can be monitored on the computer screen as they are created, allowing "retakes" to be fixed during the scanning operation. However <u>in the real world</u> operators will not watch images carefully as they are scanned on a high speed scanner, stop the feeder and retake images on the spot. Images will be inspected on different workstations and documents will have to be pulled later. The sequence number aids greatly in this process.

4. The imprint verifies that the document has been scanned/filmed, however it does not attest to the image quality.

The VersalMAGE software may be used with or without the SQ Feeder.

To Scan documents with Versalmage Select **Scan Batch** from the Scan Menu.

The First window that appears is the Setup RFS 1000 window.

This window is used to set the Mode (Film, Hybrid or Scan) and the SQ feeder String.

- Select the Mode by selecting the mode you wish to use in the first list box.
- 2. Select Simplex or Duplex (Simplex is the default).
- 3. If there is a SQ feeder select Enable to allow Versalmage to preset the SQ number into the RFS1000.
- 4. The SQ feeder

Setup RFS1000	×
General:	
Hybrid (Scan and Film)	
Film/Scan Mode:	
C Duplex (Front and Back)	
• Simplex (Front Unly)	
-SQ Feeder:	
🖸 Enable 🔿 Disable	
SQ String:	
[yyddd]{ROLL}-<000.00>	Change String
Offset: 5 📩 mm	(from Leading Edge)
Capture Imprint to Field:	Orientation:
<none></none>	→ ▼ 1 ⊅
Name	N ⁰⁰ 2 E
<u> </u>	
	OK Cancel

Fig 1 - Setup RFS 1000 Window

string will be displayed in the center of the window. To Change the SQ string select **Change String...** the SQ Feeder String Setup Window will appear.

- 5. Select the Offset from the leading edge for the printing to start (2 to 255 mm)
- 6. Select the database field to place the string that the SQ imprinter actually printed onto the document.
- 7. Select the orientation of the printing.
- 8. When Complete press OK.

Setting the SQ feeder String

The SQ Feeder string appears at the top of this window. This will change as you change the SQ feeder string.

- To change the SQ feeder string place the blue highlight on the field (1 thru 4) that you wish to change.
- 2. Press either
 - Fixed String to place a fixed string of characters into the SQ String
 - Today's Date to place today's date into the SQ String. Note that various date formats can be selected including Julian date (yyddd).
 - Roll Number to place the Roll number into the SQ String.
- 3. To place the Batch/File/Page into the SQ string place the highlight on the field you wish, then click on the Length box. Versalmage will ask you for the number of characters to be placed into the SQ String.
- 4. When you are finished the SQ feeder string will appear in the top box.
- 5. Press OK to return to the Setup RFS 1000 Window.

SQ Feeder String Setup 🛛 🕅 🕅
Current SQ String:
[yyddd]{ROLL}-<000.00>
Build String:
Contents Length
Field1: [yyddd] 5
Field2: {ROLL} 6
Field3: - 1
Field4:
Batch Blip Field: 0
File Blip Field: 3
Page Blip Field: 2
Fixed String Today's Date Roll Number
OK Cancel



Set Fixed String	00
Enter String	
123	_
	_
OK Cancel	



Select Da	ate Format	\times
Select	Date Format	
Format:	yyddd 💌	
	mmddyy yymmdd	
	m/d/yy	
	m/d/yyyy	

Fig 4 - Select Date Format

When you are finished with the Setup RFS 1000 window Versalmage will ask for the roll number unless Scan only was selected.

The Versalmage Batch Scan Window will appear.

Scan Mode can be changed in preferences, imaging	🖿 Versalmage - Batch Scan	Push to Start Scanning
options	Scan Mode: Single page TIFF images, Folder Files	
	Batch Number: 1	
	Page Count: 0	
	Folder Count: 1 Page #: 0	
Image address of	ISIS Driver: CANONFLM Pause	
just scanned	C:\VCARPLUS\2LEVEL\ROLL0100\0000000.FLD	Displays the
	🗹 Display Images 🛛 🗖 Scan Both Sides (Duplex)	ISIS setup
	New Folder New Batch Setup Scanner	WINDOWS

Fig 5 - Versalmage Batch Scan Window

The Setup scanner displays the ISIS setup window. This is important to do for the following functions:

- 1. Patch code detection.
- 2. SQ Feeder enabling

Scanner Settings			8
Mode: Black and White Dither: None Dots per inch: 200	Brightness ○ Manual ■ <u>×</u> Dar <u>k</u> en	← Automatic ▼ □ Auto Norm Lighten	OK Default Cancel
Page Size: Letter - 8.5 x 11 in	Contrast	C Automatic	More
CANONFLM Version 1.6			Furners

Fig 6 - Scanner setup window with "more..." button

- 3. 200 x 100 fast scan mode selection.
- 4. Paper size detection which adjusts the image "pulldown".

5. Auto Stop feature, allowing to set the feeder for auto stop after a certain time interval.

These options can ONLY be enabled by using the Scanner setup window

anon RFS 1000 Special Features	I
┌ Scan <u>O</u> ptions	1
☑ High Speed Scanning	OK
☐ <u>A</u> uto Stop 	Cancel SO Feeder
☐ <u>P</u> age Size Detection	Defaults
Patch Detection	
Scan Mode	<u>H</u> elp
C Scanner Only	
O Hybrid	
O Filmer Only	
Image Address of Last Page Scanned	
Batch Number 0	
File 0	
Page Number: 0	
]

Fig 7 - ISIS "More" Window

SQ Feeder Options
Endorser Options Enable SQ Feeder <u>SQ</u> String 97251222-<00000>
Starting Number: Step Number: 1 Rotation O degree Printing Y 5
OK <u>D</u> efault Cancel <u>G</u> et Values from Scanner

Fig 8 - ISIS SQ Feeder Option Window